



HÆGER

Sous-chef 20 MW-70W.006A



(478 x 382 x 288 mm)

Features

Características / Características / Caracteristiques

6
POWER
Settings

6 Power Settings

6 Níveis de Potência
6 Niveles de Potencia
6 Niveaux de Puissance



30 Minutes timer

Temporizador de 30 minutos
Temporizador de 30 minutos
Minuterie de 30 minutes



DEFROST

Defrost Function

Função de Descongelação
Función de Descongelación
Fonction de Dégivrage



Cooking End Signal

Aviso sonoro indicador de fim
Aviso sonoro indicador de final
Avertisseur sonore indicateur de fin



Inner Light

Inner light

Iluminação interior
Iluminación interior
Eclairage intérieur



24.5cm

24.5cm glass rotating plate

Prato rotativo em vidro de 24.5cm
Plato giratorio en vidrio de 24.5cm
Plateau rotatif en verre avec 24.5cm



Pull handle

Pull handle to open door

Puxar a alça para abrir a porta
Tire de la manija para abrir la puerta
Tirer la poignée pour ouvrir la porte



700 W

Power: 700 Watts - 230V~, 50Hz

Potência: 700 Watts - 230V~, 50Hz
Potencia: 700 Watts - 230V~, 50Hz
Puissance: 700 Watts - 230V~, 50Hz



6 Power Settings
6 Níveis de Potência
6 Niveles de Potencia
6 Niveaux de Puissance



30 Minutes timer
Temporizador de 30 minutos
Temporizador de 30 minutos
Minuterie de 30 minutes



24.5cm glass rotating plate
Prato rotativo em vidro de 24.5cm
Plato giratorio en vidrio de 24.5cm
Plateau rotatif en verre avec 24.5cm



Pull handle to open door
Puxar a alça para abrir a porta
Tire de la manija para abrir la puerta
Tirer la poignée pour ouvrir la porte

Cavity dimensions: W307 x D306 x H217.5 (mm)
Unit dimensions: W451 x D345 x H256.5 (mm)
Net weight: 10.1 Kg


Meet the family



1 Unidade (478 x 382 x 288mm)



Código EAN



51608475016332